



Banjo Brothers

Pocket Messenger Bag

Instructions

For the 01120 Pocket Messenger Bag

Wearing it:

(This really should be self-explanatory, but here's a photo.)



Wear on left or right shoulder with the pouch on your back. Do not wear in front.

Folding it:

(Less self-explanatory.)



1. With the flap-side up, start folding toward the top

2. Keep folding upward

3. Keep folding. We're not paying you to stand around.

4. Don't fold *up* anymore. Start rolling it right to left

5. Slip the elastic around the tight roll. Place in pocket.

General comments

- The pouch will sometimes want to slide around to your front, especially on a windbreaker. Slide the bag on your back toward the side that you have the strap on. (For example, if your strap on is on the left shoulder, slide the bag left).
- It is designed to be compact and will only carry moderate loads (8 lbs. max - roughly a six-pack). Sharp objects will tear the fabric.
- Your bag is built to be used in rain or shine. If it gets dirty, clean it with soap and water and air dry. Do not put it in the dryer unless you want it to melt. Solvents can and will deteriorate the synthetic fibers. Sustained exposure to sunlight will also cause some fading and deterioration to all fabrics. We can't defeat the laws of chemistry and physics, but we do our best to resist them.

Contact customerservice@banjobrothers.com if you have additional questions